

Description	P/N
Evaporator Assembly	004-0257-1
Compressor Pallet Assembly	004-0550-1
Condenser Assembly	100-0356-1
Compressor Assembly	100-0450-1
Blower Ass'y – Motor & Wheel Only	ES73175-9
Blower Assembly	120-0261-1
Compressor Assembly	120-0450-1
Blower Assembly	100-0253-1
Evaporator	133-0250-1
Blower Assembly	133-0253-1
Blower Assembly	120-0260-1
Aft Evaporator Assembly	133-0260-1
Condenser Assembly	133-0350-1
Compressor	133-0450-1
Soft Start Assembly	135-0552-2
Motor Assembly	135-0570-1
Blower Assembly	145-0408-1
Compressor Assembly	201-0450-2
Soft Start Assembly	135-0552-1
Blower Assembly	145-0174-1
Blower Assembly	145-0407-1
Blower Assembly	145-0407-2
Blower Assembly, Condenser	206-0356-3
Controller	222-0750-2
Controller	222-0750-3
Blower Assembly	227-0205-1
Compressor Assembly	201-0450-1
Mixing Box Assembly	201-0657-1
Mixing Box Assembly	201-0657-2
FWD, Evaporator Assembly	227-0250-1
Controller	201-0750-1
Controller	201-0750-2
Controller	201-0750-3
Blower Assembly	145-0401-1
Compressor/Condenser Assembly	227-0550-1

Compressor/Condenser Assembly	227-0550-2
Evaporator Assembly	222-0250-1
Blower Assembly	415-0252-1
Pallet Assembly	415-0550-1
Pallet Assembly	415-0550-2
Aft, Blower Assembly	45-0261-2
Heater Panel Assembly	45-0282-2
Fwd. Evaporator Assembly	300-0250-1
Aft Evaporator Assembly, Fwd	300-0260-1
Aft Evaporator Blower	300-0261-1
Aft Evaporator Assembly, Aft	300-0270-1
Aft Evaporator Blower	300-0271-1
Power Panel Assembly	45-1756-1
Compressor Mount Assembly	300-0453-1
Mixing Box Assembly	300-0657-1
Mixing Box Assembly	300-0657-2
Heater Assembly	300-0670-1
Fwd Evap Blower Ass'y	66-0251-1
Aft Evaporator Blower Ass'y	66-0261-1
Controller	300-0750-1
Controller	300-0750-2
Controller	300-0750-3
Thermistor Probe Assembly	300-0751-1
Evaporator/Blower Assembly	76-0255-2
Load Shed Box Assembly	85-02-204-2
Load Shed Box Assembly	85-02-204-3
Load Shed Box Assembly	85-02-204-5
Blower Assembly	85-02-205-2
Fan Assembly	98-0902-1
Blower Ass'y	B215M10C1011
Blower Assembly	B215M10C1012
Motor, 27 VDC 1.46 HP	ES61107-1
Motor, 27 VDC 2.6 HP	ES61108-1
Motor – Compressor	ES61110-1
Motor – Compressor	ES61110-2
Motor – Compressor	ES61110-3
Avionics Blower Assembly	B215M10C2001

Compressor Assembly	JBS224-2
Condenser Assembly	45-0350-1
Motor-Compressor	ES61134-1
Motor-Compressor	ES61134-3
Fwd Evap Blower Ass'y	66-0251-4
Fwd Evap Blower Ass'y	66-0251-4SB
Aft Evaporator Blower Ass'y	66-0261-2
Aft Evaporator Blower Ass'y	66-0261-3
Motor, Brushless DC	ES61137-1
Motor, Brushless DC	ES61137-2
Compressor/Condenser Pallet Assembly	76-0551-1
Filter/Relay Assembly	76-0558-1
Blower Assembly	ES73103-1
Blower Assembly	ES73103-2
Blower Assembly-Flame Arrestor	ES73107-2
Evaporator/Blower Module Assembly	85-02-203-1
Blower Assembly	85-02-205-1
Fan Assembly	98-0900-1
Motor Assembly	98-0906-1
Blower	98-0907-1
Blower Assembly	B212M20C1015
Blower Assembly	B212M20C1016
Soft Start	ES59185-1
3.5 H.P. Motor	ES61100-1
Motor – Compressor	ES61110-4
Motor, Brushless	ES61136-1
Motor, Brushless	ES61136-2
Blower Ass'y L.H.	ES73175-1
Fan Vaneaxial 28 VDC	ES73127-2
Blower Ass'y R.H.	ES73175-2
Compressor Assembly	JBS222-1
Pallet Assembly, Compressor/Condenser	JBS5004-1
Blower Ass'y R.H.	ES73175-4
Blower Ass'y	JBS13016-11
Blower Motor	ES73176-1
Blower Ass'y	JBS13016-10
Pressure Switch Assembly	JBS2020-1

Pressure Switch Assembly	JBS2020-3
Pressure Switch Assembly	JBS2020-5
Pressure Switch Assembly	JBS2020-6
Pressure Switch Assembly	JBS2020-7
Pressure Switch Assembly	JBS2020-8
Pressure Switch Assembly	JBS2020-9
Pressure Switch Assembly	JBS2020-10
Pressure Switch Assembly	JBS2020-11
Pressure Switch Assembly	JBS2020-12
Pressure Switch Assembly	JBS2020-13
Blower Ass'y	JBS13016-3
Compressor/Condenser Pallet Assembly	JBS5006-1
Avionics Blower Assembly	B215M1003101
Evaporator Assembly	JBS2040-1
Evaporator Assembly	JBS2040-2
Evaporator Assembly	JBS2040-3
Evaporator Assembly	JBS2040-4
Evaporator Assembly	JBS2040-6
Evaporator Assembly	JBS2040-7
Condenser Coil	JBS464-17
Condenser Coil	JBS464-3
Blower Assembly	145-0409-1
Evaporator/Blower Module Assembly	76-0250-1
Evaporator/Blower Module Assembly	76-0250-2
Evaporator/Blower Module Assembly	76-0250-3
Evaporator/Blower Module Assembly	76-0250-4
Pallet Assembly, Compressor/Condenser	JBS5010-1
Compressor Assembly	JBS204-1
Compressor Assembly	JBS221-1
Compressor Assembly	JBS223-1
Motor Assembly – Flame Arrestor	JBS26-1
Heater/Ejector Assembly	JBS880-3
Heater Controller	JBS881-1
Heater Controller	JBS881-2
Heater/Ejector Assembly	JBS882-1
Controller	JBS884-2
VSO Assembly	JBS885-3

VSO Assembly	JBS885-4
Aft Evaporator Assembly	PC9-0254-1
Compressor Assembly	PC9-0450-2
Pallet Assembly Compressor Condenser	JBS400-7
Motor Assembly	004-0255-2
Controller	JBS884-3
Bleed Air Regulator Valve	JBS889-1
Bleed Air Regulator Valve	JBS889-2
Compressor Assembly	JBS98-3
Compressor Assembly	JBS98-4
Compressor Assembly	JBS98-8
Compressor Assembly	JBS98-12
Compressor Assembly	JBS98-13
Compressor Assembly	JBS98-14
Evaporator Assembly, AFT	PC9-0251-1
Evaporator Assembly, AFT	PC9-0251-2
Drive Pulley	133-1400-1
Blower Assembly - Motor and Wheel Only	ES73175-10
Blower Assembly - Motor and Wheel Only	ES73175-11
Motor, Brushless DC	ES61137-1
Blower Assembly	44-1250-1
Condenser Coil	JBS464-14
Fwd Evaporator Assembly	66-0250-1
Fwd Evaporator Assembly	66-0250-2
Fwd Evaporator Assembly	66-0250-3
Fwd Evaporator Assembly	66-0250-4
Fwd Evaporator Assembly	66-0250-5
Fwd Evaporator Assembly	66-0250-6
Blower Assembly	145-0175-1
Blower Assembly	ES73073-1
Blower Assembly	ES73073-2
PC Board Assembly	85-02-304-1
PC Board Assembly	85-02-304-2
PC Board Assembly	85-02-304-4
Blower	ES73108-1
150 Amp BLDC Motor	ES61141-1
151 Amp BLDC Motor	ES61141-2

152 Amp BLDC Motor	ES61141-7
Blower/Bracket Assembly	B215M10C1009
Compressor Assembly	JBS57-98
Compressor Assembly	JBS57-99
Evaporator Housing Assembly	415-0251-1
Evaporator Housing Assembly	415-0251-2
Evaporator Housing Assembly	415-0251-3
Evaporator Assembly	415-0250-1
Evaporator Assembly	415-0250-2
Load Shed PC Board Assembly	85-00-07-8
Compressor Assembly	JBS221-7
Blower Assembly	76-0251-1
Condenser/Compressor Pallet Assembly	180-0550-1
Compressor Assembly	180-0450-1
Motor Assembly	98-0908-1
Motor Assembly	98-0908-2
Motor Assembly	98-0908-3
Compressor/Drive Motor Assembly	180-0551-1
Mixing Valve	180-0654-1
Evaporator/Blower Assembly	76-0255-1
Pallet Assembly Compressor Condenser	JBS5001-1
Motor Assembly	76-0553-1
Compressor Assembly	JBS221-5
Blower Subassembly	145-0260-1
Forward Control Panel Assembly	PC9-0752-5
Fwd Evaporator Assembly	PC9-0253-1
Blower Assembly	145-0250-1
Compressor Assembly	JBS14116-1
Compressor/Drive Assembly	222-0450-1
Compressor Drive Assembly	222-0460-1
Compressor Assembly	220-0451-1
Compressor Assembly	220-0451-2
Blower Assembly	145-0402-1
Blower Assembly	145-0170-1
Blower Assembly	145-0406-1
Heater Assembly	PC9-0850-1
Evaporator/Blower Assembly	JBS2046-1

Pallet Assembly	JBS5005-1
Pallet Assembly	JBS5005-2
Evaporator Assembly	JBS12055-2
Servo Assembly	98-0650-1
Fan Motor Assembly	JBS13020-1
Compressor, Assembly Modified	JBS4172-1
Evaporator Assembly, Forward	PC9-0250-1
Evaporator Assembly, Forward	PC9-0250-2
Blower Assembly	JBS275-1
Blower Assembly	JBS275-2
Compressor Assembly	JBS201-1
Compressor Assembly	JBS201-4
Compressor Assembly	JBS201-14
Compressor Assembly	JBS201-16
Compressor Assembly	JBS201-20
Compressor Assembly	JBS201-23
Pallet Assembly Compressor Condenser	JBS5001-4
Flexible Hose Assembly	Various
Compressor Assembly	180-0453-1
Blower Assembly	145-0252-1
Fan Assembly Vaneaxial	JBS131-9
Fan Assembly Vaneaxial	JBS131-19
Blower Assembly	145-0173-1
Evaporator/Blower Assembly	180-0250-1
Evaporator/Blower Assembly	180-0250-2
Compressor Assembly	201-0450-3
Heater/Ejector Assembly	145-0850-1
Fan Assembly	34-030-19
Compressor Assembly	133-0450-3
Motor and Blade Assembly	ES73131-2
Shut-Off Valve	ES26185-1
Shut-Off Valve	ES26185-2
Compressor Assembly	SF50EC-3000-2
Compressor Assembly	SF50EC-3000-3
Compressor Assembly	SF50EC-3000-4
Compressor Assembly	SF50EC-3000-5
Compressor Assembly	SF50EC-3000-6

Blower, Puller	S-6085EC-2
Blower, Puller	S-6085EC-3
Compressor Assembly	SF50EC-3010-1
Compressor Module	PC24EC-3001-V56
Motor Brushless	ES61138-1
Comp/Drive Motor Beam Assy	227-0551-1
COCKPIT EVAP MODULE	PC24EC-6005-1
Evaporator Assembly	222-0253-1
Assembly Condenser, (Beveled)	412AC-7012-2
Blower Assembly - 7" V.A.	412AC-7058-16
Assy, DHE Fan	PC24EC-9603-1
Assy, DHE Fan	PC24EC-9604-1
Assembly - Evaporator (Aft)	412AC-6004-4
Assembly - Evaporator (Aft)	412AC-6008-1
Assembly - Evaporator (Aft)	412AC-6010-1
Assy, Fan - DHE	S-6229EC-2
Assy, Fan - DHE	S-6229EC-3
Assembly - Compressor	412AC-3542-2
ASSEMBLY, TOP, COCKPIT HEATER	PC24EC-9002-1
ASSY, HEATER ELEMENT, COCKPIT HEATER	PC24EC-8001-1
COMPRESSOR ASSEMBLY	S-3008EC-3
COMPRESSOR ASSEMBLY	S-3008EC-4
COMPRESSOR ASSEMBLY	S-3008EC-5
COMPRESSOR ASSEMBLY	S-3008EC-6
COMPRESSOR ASSEMBLY	S-3008EC-8
COCKPIT EVAP MODULE	PC24EC-6003-1
COCKPIT EVAP MODULE	PC24EC-6003-2
SUB-MODULE, COCKPIT EVAP, TOP HALF	PC24EC-6018-1
SUB-MODULE, COCKPIT EVAP, BOTTOM HALF	PC24EC-6016-2
SUB-MODULE, COCKPIT EVAP, BOTTOM HALF	PC24EC-6016-3
SUB-MODULE, COCKPIT EVAP, BOTTOM HALF	PC24EC-6017-1
ASSY, MODULE, CABIN EVAP	PC24EC-6213-1
ASSY, MODULE, CABIN EVAP	PC24EC-6214-1
ASSY, MODULE, CABIN EVAP	PC24EC-6214-2
ASSEMBLY, FAN - RIGHT	PC24EC-6350-22
ASSEMBLY, FAN - LEFT	PC24EC-6350-21
ASSY, BLOWER MOTOR, RIGHT	PC24EC-6350-24

ASSY, BLOWER MOTOR, LEFT	PC24EC-6350-23
ASSEMBLY, MOTOR AND PCB	S-6137EC-31
ASSEMBLY, MOTOR AND PCB	S-6137EC-32
Assy, Compressor	S-3038EC-1
ASSY, COMPRESSOR	S-3036EC-1
ASSY - COMPRESSOR	A119-3040-1
ASSY - COMPRESSOR MOUNT	EC135-3004
ASSY-EVAP, FWD	S-6006EC-1
ASSY-EVAP, FWD	S-6006EC-2
ASSY-EVAP, FWD	S-6006EC-3
ASSY-EVAP, FWD	S-6006EC-4
ASSY - EVAP, FWD	S-6116EC-1
ASSY - EVAP, FWD	S-6116EC-2
ASSY - EVAP, FWD	S-6116EC-3
ASSY - EVAP, FWD	S-6116EC-4
ASSY - FWD EVAPORATOR	EC135-6006-1
ASSY - FWD EVAPORATOR	EC135-6006-2
ASSY - HEAT EXCHANGER	S-6054EC-6
ASSY - HEAT EXCHANGER	S-6054EC-7
ASSY - HEAT EXCHANGER	S-6054EC-8
ASSY - EVAPORATOR HEAT EXCHANGER	S-6046EC-1
ASSY - EVAPORATOR HEAT EXCHANGER	S-6046EC-2
HEAT EXCHANGER ASSY	S-6028EC-1
HEAT EXCHANGER ASSY	S-6028EC-2
ASSEMBLY, AFT EVAPORATOR	EC135-6008-10
AFT EVAP ASSY	S-6008EC-3
ASSEMBLY-BLOWER HOUSING	S-6108EC-1
ASSEMBLY-BLOWER HOUSING	S-6108EC-2
COMP/COND PALLET ASSEMBLY	135-0550-3
COMP/COND PALLET ASSY	135-0553-1
COMP/COND PALLET ASSY	135-0566-1
COMP/COND PALLET ASSY	135-0566-2
EVAPORATOR, FORWARD	S-6029EC-1
EVAPORATOR, FORWARD	S-6029EC-2
FORWARD EVAPORATOR ASSEMBLY	100-0250-1
COCKPIT MIXER ASSEMBLY	PC24EC-9101-1
HOT AIR DISTRIBUTOR ASSY	PC24EC-9200-1

CABIN ELECTRIC HEATER ASSEMBLY	PC24EC-9306-1
ASSY, EVAPORATOR, AFT (LH)	429EC-6302-1
ASSY, EVAPORATOR, AFT (LH)	429EC-6302-3
ASSY, EVAPORATOR, AFT (RH)	429EC-6302-2
ASSY, EVAPORATOR, AFT (RH)	429EC-6302-4
ASSEMBLY, ZONE CONTROL VALVE	PC24EC-9400-1